

## The GigRig™ G2 / QuarterMaster QMX Pedaltrain Brackets



This kit contains everything you need to attach The GigRig QuarterMaster or G2 to your Pedaltrain pedalboard.



1. Turn the QuarterMaster upside down and attach the QuarterMaster / G2 brackets to the bottom of the unit with the screws provided. For the G2 the same applies. The long leg of the bracket goes to the front (blank) side of the QM, and the short leg goes towards the back (send & return) side.



2. Repeat for all the brackets. The QMX4 needs 2 brackets, QMX6, 8 and 10 you will need 3.



3. Place the QuarterMaster / G2 on the bottom rail of the Pedaltrain. Push and gently bend the long arm of the bracket underneath the Pedaltrain.



4. Secure the brackets with the re-usable cable ties that are provided as part of the kit. Trim any excess tie wrap.



Your QuarterMaster/ G2 is now attached securely to your Pedaltrain Pedalboard board!